ACMER P1 S PRO

MANUAL V1.0



Acmer Technology Co., Ltd.

Thank you for selecting our product and trusting our brand. We are dedicated to delivering superior-quality products and providing exceptional service to all our valued customers. Your support is deeply appreciated.

To assist you in utilizing and maintaining your product, we provide various support options:

Social Media Channel

To join our Facebook group and follow our Facebook page by scanning the QR code below:

Facebook Group

https://www.facebook.com/groups/1614455505653986

Facebook Page

Online Video Learning:

Learn how to operate the laser engraving machine through our official YouTube channel（@acmerlaser）

Support Email:

If you need to contact our after sales service,please feel free to email us at our support email address support@acmer3d.com.

CONTENTS

1. Disclaimer and Safety Guidelines

1. Laser engraving machine will produce laser light, it is strictly prohibited to point the laser at any living body.
2. When using the laser engraving machine, the operator and the personnel in its vicinity must wear laser safety glasses, please do not operate the laser without wearing protective glasses (laser goggles)!
3. Minors (especially children under 14 years old) must use the machine under the supervision of an adult throughout!
4. Engraving machine work will produce a lot of smoke, please place the machine in a ventilated environment before work, and ensure that there is no other flammable materials near the engraving machine, it is recommended to place a metal mat under the machine.
5. When the machine is running, please do not touch the laser beam to avoid personal injury.
6. During the engraving and cutting process, please ensure that the machine is within the visual range of the operator.
7. This machine is not recommended for commercial use.

2.Machine Parameters

Machine Size	575*560*200mm
Engraving Size	380*370mm
Machine Weight	3.6kg
Focal Length	6W: 23mm / 10W: 31mm
Laser Power	6W / 10W
Laser Wavelength	445±5nm
Power Input	DC 24V
Communication Method	USB / APP
Compatible Software	LaserGRBL / LightBurn / ACMER APP / MKSlaser
Compatible Systems	MAC, Windows, Android,iOS
Engraving Material	Wood, Bamboo, Paper, Plastic, Leather, PCB board, Aluminium oxide, Non-reflective coating and lacquered metal, Ceramic, Glass,etc.
Engraving File Format	NC, DXF, BMP, JPG, PNG, etc

3. What is in the Box

Front Profile X1

Back Profile X1

X-Axis Module X1

Optical Axis Module X1

Left Profile X1

Right Profile X1

Motherboard Socket X1

Corner Bracket X3

Motor X1

Laser Module X 1

Slider X1

Protective Eyewear X1

Adapter X1

USB Cable X1

Card reader + TF card X1

Wood Board X2

Tool Kit X1

Screw Pack X1

Wire Bracket X1

(In the bag of Hinge screw pack)

Measuring Aluminum Column X1

Sealing Strip X1

4. Assembly Steps

Assembled Machine



Step1. Assemble the left, right and front profiles

① Prepare the following components: Allen wrench, Step1 screw pack, left/right/front profiles, Motherboard Socket(1 piece), Corner Bracket (1 piece).

② Start by attaching the right profile to the Corner Bracket and the left profile to the Motherboard Socket. Then, align and secure the front profile to the left and right profiles.

(Pay attention to the positioning and orientation of the aluminum profiles. During assembly, ensure that the profiles are aligned parallel and closely with the edges of the Corner Bracket.)



③ The image below shows the frame after Step1 assembly.



Step2. Assemble the X-axis Components

① Prepare the components:screw pack, motor, optical axis module, X-Axis module, tool kit,wire bracket and slider

② Connect the motor to the optical axis module using the coupling.

③ Insert the assembled motor/optical axis components into the corresponding position of the X-Axis module, ensure that the motor socket faces the rear, as shown in the follow image.

④ Tighten the motor according to the image

⑤ Assemble the wire bracket

⑥ Assemble the slider, please pay attention to the direction of the slider.



Step3. Assemble the whole frame

① Prepare the following components: back profile, screw pack, Corner Bracket (2 pieces), tool kit(allen wrench and open-end wrench).

② Loosen the top two pulleys on the left and right sides of the X-Axis slightly.

③ Insert the assembled frame in Step1 into the pulleys of the X-Axis and tighten the loosened pulleys, as the following image shows



④ Attach the left and right profiles to the Corner Bracket .

Pay attention to the positioning and orientation of the aluminum profiles, with the printed side facing outwards.

During assembly, ensure that the profiles are aligned parallel and snugly against the Corner Bracket .



③ Secure the back profile to the left and right profiles, as the following image shows.



Step4. Assemble Y-Axis Belts

Components required: Allen wrench,STEP4 screw pack.

①



The belt should be installed in the orientation shown above, with the teeth of the belt facing down and meshing with the gears.

②

Place the T-nut assembly into the groove with the long side parallel to the groove.

With the belt tightened, tighten the screws to keep the long side of the T-nut perpendicular to the groove.



Press down on the T-nut while turning the wrench clockwise so that the long side of the T-nut is perpendicular to the groove.You can also use an Allen wrench to rotate the T-nut.

Step5. **Assemble the Laser Module**

① Prepare the following component: Laser Module

② Insert the laser module into the slider of the X-Axis and tighten the knob screw on the side of the slider to secure the laser module.

Step6. **Secure the wires**

① Prepare the following components: tool kit (zip ties , sealing strip).

② Connect the unconnected ports to the corresponding interfaces based on the labels on the wires.

③ Use zip ties to secure the wires to the left slider, secure the corrugated tube to the left slider's corrugated tube bracket,Secure the zip tie to the black heat shrink tubing.



④ Embed the "X" wire into the back of the X-Axis profile. Seal the profile slot with sealing strip, and then fix the corrugated tube to the X slider's corrugated tube bracket.



5.Important Usage Tips

Focusing Tips:

1. The focal length of the laser module is fixed and cannot be changed.
2. For 6W laser modules, the focal point is located 23 mm below the bottom of the aluminum profile. For 10W laser modules, the focal point is located 31 mm below the bottom of the aluminum profile.
3. For 6W and 10W machines, we provide the user with measuring aluminum posts to help locate the laser focus.
4. The laser will achieve its maximum engraving effect when it is focused on the surface of the material being engraved.



Adjusting the Pulley:

Adjusting the gap between the pulley and the track by rotating the hex eccentric nut. The desired state after adjustment should be as follows: when the machine is tilted at a 45° angle, the slider should slide smoothly without any wobbling.

6.Software Tutorials

ACMER laser engraver supports the most popular engraving software LaserGRBL and LightBurn.

LaserGRBL is an open source, easy to use and powerful software that is perfect for novice users to use, but LaserGRBL only supports Windows systems (Win XP/Win 7/Win 8/ Win 10/Win 11). For Mac users, you can choose to operate LightBurn, which is also an excellent engraving software, but it costs $60 (with a free one-month trial for the first installation), and this software also supports Windows systems.

If you want to download and install LaserGRBL, you can get the data directly from the TF card, or you can visit the official website of LaserGRBL to download; for LightBurn users, you can visit LightBurn official website to download.

Note

If you are using the software for the first time, please get the driver file from the TF card "Software->Drivers" file and install it.



6.1 LaserGRBL Tutorials

6.1.1 Use the USB cable to connect the computer to the machine and power on the machine.

6.1.2 Select the correct COM and Baud, then click "Connect".

6.1.3 Start engraving

① Click the "Open File" button.
② Select the engraving file.
③ Click "OPEN".

⑥ Brightness, contrast, black and white limit adjustment.
⑤ Select the engraving mode.
④ Adjust the engraving quality
⑦ Click "NEXT".

⑧ Select the engraving speed.(suggest to refer to the engraving parameter table).
⑨ Select "Laser Mode", "M4" for engraving and "M3" for cutting.
⑩ Set the engraving power, 1000 is the maximum power.
⑪ Set the engraving size.
⑫ Click "Create".

⑮ Click "Frame" to preview the engraving boundary.
⑯ Click "Run Program" to start engraving.

6.2 LightBurn Tutorials

6.2.1 Use the USB cable to connect the computer to the machine and power on the machine.

6.2.2 Importing Devices

6.2.3 Connecting the machine

Note: Job Origin needs to be set to lower left



6.2.4 Software Settings

6.2.5 Start engraving

① Click "OPEN" to select the engraving file.
② Click "Open".

③ Click on the picture area.
④ Adjust the engraving size.



⑤ Select 'Cuts/Layers'.
⑥ Double-click the red box area.

⑦ Adjust the carving speed and carving power (suggest to refer to the carving parameter table).
⑧ Set the engraving quality.
⑨ Set the engraving mode.
⑩ Click "OK".



⑪ Click "Frame" to preview the engraving area.
⑫ Click "Start" to start engraving.

7. APP Tutorials

7.1 APP Download

Android user

Android users can scan the QR code below or directly visit the ACMER website to download.



iPhone user

Search for "MKSLaser" in App Store.



7.2 APP Connection

① Insert the TF card into the card slot.

② Power on the machine, search for the network name "ACMER_P1_SPRO_xxxxx" through the cell phone WIFI function, and enter the password to connect.

The initial password is: 12345678

③ Open the mobile app and click the icon in the upper left corner.



④ Enter the IP address, and then click "CONNECT".

Note: The default IP address is "192.168.4.1".

7.3 APP Function Introduction

You can use this function for self-creation, such as doodling, writing, etc. You can also access your phone album or take photos for engraving.

This function can be used to control the laser module movement and also to bring the laser module back into position.

Get the material provided by ACMER for you to engrave.

You can store the programs generated by the computer software to the TF card, and then access the files in the TF card for offline engraving through this function.

7.4 Operation Demo

① Select "Material".

② Select the engraving pattern.

③ Select the engraving mode.

④ Adjust the engraving parameters and click send.

⑤ Click "Confirm" to start the engraving process.

⑥ Wait for the engraving to be completed.

8. After Sale

The content of after-sales service is as follows:

1. REPLACEMENT PARTS

1.1 ACMER products are covered under a Replacement Part Program for a period of 12 months from the date of purchase.

1.2 Missing/Damaged/Defective Parts

1.2.1. Within 7 days of the delivery date, ACMER will replace any parts free of charge including shipping fees.

1.2.2. After 7 days of the delivery date, ACMER will replace any parts free of charge but the customer will be responsible for shipping fees.

1.3 Customer Damaged Parts.

1.3.1. The customer shall pay for the cost of the parts and the shipping fees.

2. CARRIER LOSS, MISSING, DAMAGED, AND DEFECTIVE PARTS

2.1 Claims for lost or damaged shipments must be reported to the carrier within the carrier's claim window, the customer needs to inform ACMER within 7 days of the delivery date. For any parts lost or damaged during shipping, the customer shall take photos or video and submit them when filling out a Service.

2.1.1. Ticket. If a daim number was issued by the carrier, please include the daim number when creating your service ticket (Report a Problem / Carrier Lost Parts.)

2.1.2. Once the carrier disupute is resolved, please provide ACMER with all communications with the carrier. It is the customer's responsibility to keep ACMER up to date with all communication with the carrier.

2.1.3. ACMER will work with the customer on replacing the parts in the claim.

2.2 For Missing Parts, refer to section 1.2, the customer shall fill out a service ticket (Report a Problem / Missing Parts.)

2.3 For Damaged Hardware Parts, refer to section 1.2, the customer shall take photos or video and submit them when filling out a service ticket (Report a Problem / Damaged Hardware Parts.)

2.4 For Defective Electronic Parts, refer to section 1.2, the customer shall take photos or video and submit them when filling out a service ticket (Report a Problem / Defective Electronic Parts.)

2.4.1. If the part is power supply or mainboard, the customer shall ship the part back to ACMER and ACMER will send a new part.

3. GENERAL SUPPORT

For information and support on building and operating your ACMER Laser Engraving Cutting Machine, please visit the ACMER Owners Group. (https://www.facebook.com/groups/1614455505653986)

https://acmerlaser.com/

Acmer Technology Co., Ltd.

5th Floor, Shanhai Ke Chuang Yuan,Longhua Street, Longhua District, Shenzhen,China

MADE IN CHINA

https://www.facebook.com/groups/1614455505653986